

PSI Inspection Requirements

1. Ensure all photos include a visible time watermark.
2. Take photos of all cargo, packaging, and pallets.
3. Upon arrival at the warehouse:
  - Check the packing and marking.
  - Take photos of the packing and markings for records.
4. Verify the goods of each model against the packing list and loading plan in coordination with the factory.

Loading Process

- Before loading:  
Take pictures of the empty container, ensuring the container's serial number is clearly visible.



装柜验货要求

1. 确保所有照片均包含清晰可见的时间水印。
2. 拍摄所有货物、包装和托盘的照片。
3. 到达仓库后：
  - 检查包装和唛头
  - 拍摄包装和唛头的照片以备记录。
4. 与工厂协调，核对每种型号的货物是否与装箱单和装货计划一致。

装柜流程

- 装柜前  
拍摄空柜的照片，确保集装箱的序列号清晰可见。



Confirm and photograph that the inside of the container is free from damage or issues.

- During loading:  
Take photos of the loading process in at least 2-3 different stages.

确认并拍摄集装箱内部无损坏或问题。

- 装柜时  
拍摄至少 2 - 3 个不同阶段的装柜过程。



- After loading:  
When the container is full, close the left side of the container door and take a photo with the container's serial number visible.

After both doors are closed and the container is sealed, take a photo showing the seal in place.

当集装箱装满时，关闭集装箱门左侧，并拍摄一张照片，确保集装箱的序列号清晰可见。

在两扇门均关闭且集装箱铅封后，拍摄一张显示铅封已正确安装的照片。

